



# ENDURE USER GUIDE

Read Me to Get the Most Out of  
Your Device...



# 1 Endure Quick Start Guide: English



**Model: T2**


## 2 Charge Your Headset

Your headset has been given an initial partial charge to get started, but for best results charge it using the supplied USB cable and adaptor until the indicator light turns white.

- > Charge the Endure whenever it announces the battery is **Very Low**.
- > Your headset features Rapid Charge technology. It will charge to 50% capacity in just 30 minutes. A full charge takes about 2 hours.
- > During charging, the indicator light flashes red.
- > When the light goes white, the charge is complete.
- > The Endure features an iPhone headset battery meter so you can check your battery status at a glance.

USB Connector  
(lift cover to access)

Power  
Switch




## 3 Wearing the Endure

You can wear your headset on either ear.

For best results:

- > Position the hook and ear gel as shown here.
- > Make sure the headset is angled towards your mouth.



## 4 Pair Your Headset

1. Slide the power switch across to turn the Endure on.
2. Put the Endure in your ear.
3. The first time you use the Endure it will go straight to pair mode and talk you through the pairing process.

For subsequent pairings, make sure the Endure is not connected to any phones, then hold down the **Command** button. The Endure will announce it is going into pairing mode.

**Tip:** The pairing code is **0000** (four zeros).

Pairing mode will time out after 2 minutes. To go back into pairing mode, press and hold the **Command** button. To cancel pairing mode, turn the Endure off and back on again.

## 5 Transfer Your Phonebook

Once the pairing is complete, your headset will attempt to transfer your phonebook contacts so that it can announce the names of incoming callers. Please accept any connection requests on your phone from the Endure and wait for the transfer to finish.

Some phones do not support automatic phonebook transfers. If the Endure announces that this is the case, you need to go to your phone's address book and send contacts via Bluetooth to the Endure.

See "Phonebook Troubleshooting" or [www.blueantwireless.com](http://www.blueantwireless.com) for help.

**Note:** Whenever you add contacts to your phone in future you must update your phonebook on the Endure: with the headset connected to your phone but not on a call, hold down the **Command** button for 3 seconds to initiate a phonebook update.

## 6 Making Calls

### Voice Dialing

To use this feature your phone must support voice dialing over

Bluetooth.

1. Double click the **Command** button.
2. The Endure activates your phone's voice dial feature (if available).

Once you have activated the voice dial feature, you are using your phone's voice recognition software. **Please check your phone manual** to find out what commands your phone supports.

- > On the iPhone 4S this command activates Siri. There's no need to touch or unlock your phone. **Note:** Siri must be enabled on your phone. Go to **Settings > General** on your iPhone and check that **Siri** is set to **ON**.
- > Android™ users: use this command to activate Google Voice Actions (if available). **Note:** Depending on your handset, you may need to disable the phone password lock to use voice dialing over Bluetooth. Check your phone manual for further information on this feature.

## Other Ways To Make Calls

- > Dial the number on your phone. The audio automatically transfers to the headset.
- > Hold down **Vol +** for 1 second to redial the last outgoing call.
- > Hold down **Vol -** for 1 second to call back the last incoming call.

## 7 Taking Calls

When the phone rings, you can answer with your voice: wait for the prompt to ask you if you want to take the call, and then say **Answer** or **Ignore**.

If you don't want to wait for the prompt, or you are in a noisy place:

- > Click the **Command** button once to accept the call.
- > Double click the **Command** button to reject the call.

During a call, click the **Command** button to end the call.

## 8 Multipoint

Up to 2 phones can connect to the Endure at the same time. To pair a second phone:

1. Use your phone's Bluetooth menu to disconnect the existing paired phone from the Endure.
2. With the Endure switched on, hold down the **Command** button until the Endure starts to talk you through the pairing process.
3. When the pairing is complete, use the Bluetooth menu on each phone to reconnect them to the Endure.

When you have 2 phones connected, you can always answer a call on either phone. If you initiate a call through the Endure, or activate

phone voice dialing, it will happen on the “primary phone”: the one that connected to the headset first.

## 9 Listening to Audio

The Endure supports A2DP audio streaming: if your phone or Bluetooth device supports the A2DP profile then simply start playing music or any other audio (including directions from a GPS application on the phone) and it will automatically transfer to the headset.

The audio will mute automatically if you make or receive a phone call, and resume when the call ends.

**Note:** The Endure only supports A2DP bluetooth audio streaming from one phone at a time.

## 10 Reset your Endure

If you are having problems with the Endure, you can reset it and start again:

1. Disconnect the Endure from your phone by deleting the pairing from your phone's Bluetooth menu.
2. Turn your phone off and back on again to clear its memory.
3. With the Endure switched on, but not connected to any phones, hold down all three buttons (**Vol +**, **Vol -**, and the **Command** button) for about 3 seconds.

The Endure will reset and go straight to pairing mode. You will now need to pair your phone with the Endure again.

## 11 Free Android Application

- > Reads your incoming text messages
- > Helps with pairing and setup

Go to the Android Market and search for “**BlueAnt**” to download and install this free application. Once the application is installed you will hear your text messages read aloud automatically on your BlueAnt device as they come in.

Supports Android handsets running Android version 2.1 or above.

Scan this code on your phone with a QR code reader to download the application:



Android is a trademark of Google, Inc, and its use is subject to its permissions.

## 12 Phonebook Troubleshooting

When you pair your phone the Endure attempts to transfer the contacts from your phonebook so that it can announce the names of incoming callers.

**Note:** If your phone prompts you to allow a connection to the Endure, you **must** select “YES” or “OK”.

### 12a Android™


On Android devices a message about the phonebook transfer may appear in the notifications area at the top of the screen.

In order to transfer your contacts you must swipe your finger over this message and accept the phonebook transfer request from the Endure.

If you miss this step you will need to:

1. Delete the pairing from your phone.
2. Power the phone off and back on.
3. Reset your Endure and pair it with your phone again.


This is due to the way the Android PBAP request system works.



## 12b BlackBerry®

If you are using a BlackBerry smartphone you may see a message like this one during the phonebook transfer.

Select “Don’t ask this again” so that a tick appears in the box, and then choose “YES”.



## 12c Automatic Transfer Not Supported

Some phones do not support automatic phonebook transfers. If this is the case on your phone the Endure will announce that it cannot transfer the contacts automatically:

1. Go to your phonebook and select the contacts you want to send to the Endure. Choose the option to “Mark All” or “Select All” if this is available on your phone (if this is not available, you will need to transfer each contact individually).
2. Select the option on your phone to “send” or “beam” contacts, business cards, or v-cards via Bluetooth, and select the Endure from the list of Bluetooth devices. See your phone’s manual for help with this step.

## 12d Phonebook Transfer Not Supported

Some phones do not support phonebook transfers at all.

In order to transfer your phonebook, your phone must support either the Phonebook Access Profile (PBAP), AT commands, or the Object Push Profile (OPP).

If your phone does not support any of these Bluetooth profiles, then you will not be able to copy your contacts to the Endure. When you receive a call, the Endure will read out the caller's number instead.

## 13 Button Commands

Function	Do This
Activate voice dialing, Siri or Google Voice Actions (if available) on the (primary) connected phone	Double click the <b>Command</b> button
End a call or cancel a phonebook transfer/update	Click the <b>Command</b> button
Redial last outgoing call	Hold down <b>Vol +</b> for 1 second
Call back last incoming call	Hold down <b>Vol -</b> for 1 second

**Function****Do This**

Disconnect your phone

Click **Vol +** and **Vol -** together when not on a call

Reconnect your phone

Hold down **Vol +** for 1 second

Update phonebook

Hold down the **Command** button for 3 seconds (when the Endure is connected but not on a call)

Mute/unmute the microphone during a call

Hold **Vol +** and **Vol -** together until the Endure beeps twice (about 1 second)

Transfer audio to the phone

Click **Vol +** and **Vol -** together during a call

Hold active call and switch to incoming or held call

Hold down **Vol +** for 1 second

End active call and answer a new incoming call

Hold down **Vol -** for 1 second

## Function

## Do This

Call conference (if supported by your phone and network)

Hold the **Command** button for 3 seconds

## 14 Help and Support

This guide is just to get you started. If you are having trouble getting the Endure to work, please visit [www.blueantwireless.com](http://www.blueantwireless.com) for online help, support, and troubleshooting tips.

Please contact us before returning the Endure to a store and we will help you through any difficulty you may have.

## 15 Contact Us

**North America:** 1 855 9 258 3268

**Spain:** 900 838 030

**Australia:** 1300 669 049

**Hong Kong:** 800 905 394

**New Zealand:** 0800 443 122

**Singapore:** 800 130 1940

**UK:** 0800 285 1272

**Thailand:** 001 800 13 203 2852

**France:** 0800 913 467

**India:** 000 800 100 4103

[www.blueantwireless.com/support](http://www.blueantwireless.com/support)



## HELP AND SUPPORT



Visit **[register.blueantwireless.com](http://register.blueantwireless.com)** to register your BlueAnt device.



Visit **[www.blueantwireless.com/support](http://www.blueantwireless.com/support)** for online help and support or to contact the BlueAnt Technical Support team.



North America	Australia	New Zealand	UK
1 855 9 258 3268	1300 669 049	0800 443 122	0800 285 1272



Visit **[www.blueantwireless.com/buy](http://www.blueantwireless.com/buy)** to buy BlueAnt products, accessories and spare parts.