# RIBBON
USER GUIDE

**Read Me to Get the Most Out of Your Device...**

BlueAnt

Welcome to the **BlueAnt Ribbon: Stereo Bluetooth Streamer**.

With a simple twist you can be wearing the Ribbon and ready to go.

The Ribbon delivers the highest fidelity of sound from your wireless bluetooth audio source to our true-to-life sound ear buds, your own headphones or a speaker or dock with 3.5mm audio input.

The intuitive controls make controlling your music or making and taking calls a breeze.

You can also use your Ribbon in your car or your home with the supplied cable.

Indicator Light

Volume
Controls

Play/Pause

Microphone

BlueAnt

Charging
Port

Headphone/
Speaker
Socket

BlueAnt

Charge the Ribbon

The Ribbon has been given an initial partial charge, but for best results we recommend you fully charge it using the supplied USB cable and adaptor.

> A full charge takes about 2 hours.

> During charging, the indicator light is solid red.

> When the light goes solid white, the charge is complete.

> The Ribbon features an iPhone battery meter so you can check your battery status at a glance.

Pair Your Phone or Bluetooth Streaming Device

To get started you need to pair the Ribbon with your phone or device.

1. Hold down ▶ for about 3 seconds until the LED starts flashing to switch the Ribbon on and go straight to pairing mode.

2. Go to your phone or device's Bluetooth menu.

3. Select **Pair** or **Add New Device**.

4. Select the BlueAnt Ribbon.

Note: If requested, the pairing code is **0000** (four zeros).

Streaming from Another Phone

In order to stream from another phone you will need to pair the phone with the Ribbon.

To put the Ribbon back into pairing mode:

1. Switch the Ribbon off (hold down ▶ for about 3 seconds).
2. Hold down ▶ for about 5 seconds, until the LED starts flashing.

The Ribbon will switch on and go straight to pairing mode, Follow the instructions above to pair your phone or Bluetooth streaming device.

Note: When powered on, the Ribbon will try to connect to the last phone it was connected to. To swap the source phone for streaming, you need to disconnect the currently streaming phone, go to the Bluetooth menu on the new phone, then select the Ribbon and connect.

This enables you to easily switch the Ribbon between phones.

Using your Ribbon with a Hi-Fi, Speaker or Dock

To use your Ribbon with your Hi-Fi simply plug one end of the supplied 3.5mm stereo adaptor cable into the Ribbon headphone socket and the other end into the AUX port or 3.5mm audio input on your Hi-Fi, speaker or dock. Then, if required, set your Hi-Fi to use the AUX input.

Tip: There are separate volume controls for the Ribbon, your phone and your Hi-Fi. For best results turn your Ribbon to maximum volume and the Hi-Fi to a good listening level.

You can then use your phone to control the music, track and volume, like a remote control. Make sure the phone volume is not too low.

Using your Ribbon in the Car

To use your Ribbon in the car simply plug one end of the supplied 3.5mm stereo adaptor cable into the Ribbon headphone socket and the other end into the AUX port in your car. Then set your car stereo to use AUX input.

Tip: There are separate volume controls for the Ribbon, your phone and your car stereo. For best results please ensure your phone and your Ribbon are set to at least half volume.

You can then use your car stereo to control the volume.

Wearing the Ribbon

To wear the ribbon, simply slide it onto your shirt or t-shirt. The Ribbon has been designed to grip to the fabric of your clothes so that it stays securely in place.

Note: Damage may be caused to the Ribbon if you force it to open more than 3mm.

Tip: There are separate volume controls for the Ribbon and your phone. For best results please ensure your phone is set to at least half volume.

You can then use the Ribbon to control the volume.

Listening to Music

To	Do This
Play / Pause	Click ▶
Skip forward	Hold **+** for 2 seconds
Skip back	Hold **-** for 2 seconds
Increase volume	Click **+**
Reduce volume	Click **-**

Note: If you continue holding the + or - buttons, the Ribbon skips through one track every 2 seconds.

Using your Ribbon for Phone Calls

The Ribbon is also equipped with a microphone to allow you to make and receive phone calls. For best results please ensure the Ribbon is worn as close to the mouth as practical.

Function	Do This	When
Answer a call	Click ▶	Phone ringing
End a call	Click ▶	During an active call
Reject a call	Double click ▶	Phone ringing
Activate voice dialing, Siri or Google Voice Actions *	Double click ▶	Phone connected but not on a call
Cancel voice dialing	Double click ▶	Voice dialing active

Note: Once you have activated voice dialing you are using your phone's voice recognition software. **Please check your phone manual** to find out what commands your phone supports.

iPhone users: To use Siri it must be enabled on your phone. Go to **Settings > General** on your iPhone and check that **Siri** is set to **ON**. If you have set a passcode lock, you will need to set **Siri** to **ON** in the passcode lock menu.

Android users: Depending on your handset, you may need to disable the phone password lock to use voice dialing over Bluetooth. Check your phone manual for further information.

Switch On and Off

To	Do This
Power On	Hold down ▶ for about 3 seconds, until the LED is solid white (red if the battery charge is low)
Power Off	Hold down ▶ for about 3 seconds, until the LED flashes red

Note: The Ribbon will switch off automatically after 5 minutes if there is no phone or music source connected.

Specifications

Bluetooth 3.0

Charge time: 1 - 2 hours

Standby time: Up to 250 hours

Music play time: Up to 6 hours

The Ribbon features aptX for full 'wired' audio quality over Bluetooth on aptX enabled phones.

Android Application

> Reads your incoming text messages

> Helps with pairing and setup

Go to the Android Market and search for "**BlueAnt**" to download and install this free application. Once the application is installed you will hear your text messages read aloud automatically on your BlueAnt device as they come in.

Supports Android handsets running Android version 2.1 or above.

Scan this code on your phone with a QR code reader to download the application:

Android is a trademark of Google, Inc, and its use is subject to its permissions.

Help and Support

If you are having trouble getting the Ribbon to work, please visit **www.blueantwireless.com** for online help, support, and troubleshooting tips. Please contact us before returning the Ribbon to a store and we will help you through any difficulty you may have.

Terms and Conditions

By using this product, you are agreeing to BlueAnt's terms and conditions, available at **www.blueantwireless.com** and on the supplied warranty information card.

Please protect your ears. BlueAnt devices can reach volumes above 100 decibels. Prolonged use at high volumes may affect your hearing capacity and may result in noise induced hearing loss (NIHL). Please read the enclosed safety card for information about the safe use of BlueAnt products.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by BlueAnt Wireless is under license. Android is a trademark of Google Inc., Apple, iPhone and Siri are trademarks of Apple Inc., registered in the U.S. and other

Contact Us

North America: 1 855 9 258 3268	**UK:** 0800 285 1272
Australia: 1300 669 049	**France:** 0800 913 467
New Zealand: 0800 443 122	**Spain:** 900 838 030
Singapore: 800 130 1940	**India:** 000 800 100 4103
Thailand: 001 800 13 203 2852	**Hong Kong:** 800 905 394
Taiwan: 00 801 127 405	**China:** 400 120 0974

www.blueantwireless.com/support

HELP AND SUPPORT

Visit **register.blueantwireless.com** to register your BlueAnt device.

Visit **www.blueantwireless.com/support** for online help and support or to contact the BlueAnt Technical Support team.

North America	Australia	New Zealand	UK
1 855 9 258 3268	1300 669 049	0800 443 122	0800 285 1272

Visit **www.blueantwireless.com/buy** to buy BlueAnt products, accessories and spare parts.