


# SENSE: USER GUIDE

Read Me to Get the Most Out of Your Device...





# BlueAnt SENSE




# 1: Charge Your SENSE

Before using your SENSE, charge it using the supplied USB cable and charger:


- > A full charge takes about 2.5 - 3 hours.
- > During charging, the battery indicator light turns red.
- > When the light goes out, the charge is complete.

**Tip:** You can also charge the SENSE by connecting to your computer's USB port.



## 2: Pair the SENSE with your Phone

1. Slide the power switch to the ON position.
2. The SENSE will announce the available languages. Tap the  symbol when you hear your language.
3. The SENSE will now talk you through the pairing process.
4. The pairing code is **0000** (four zeros). **Note:** your BlueAnt SENSE will appear in the Bluetooth menu on your phone as the "BlueAnt S3".



**If you select the wrong language:** turn off your SENSE without completing the pairing. When you switch it back on your SENSE will ask you to select the language again. If this does not work, reset your SENSE and start again (see **"Reset the SENSE" on page 17**).

**If the SENSE does not go into pairing mode:** hold down the  symbol for about 6 seconds.

### 3: Transfer your Phonebook


Once the pairing is complete your SENSE will attempt to transfer the contacts from your phonebook so that it can announce the names of incoming callers. On most phones this happens automatically.

If your phone asks you to allow a connection to the “BlueAnt S3”, you **must** select “YES” or “OK”.

#### BlackBerry®

If you are using a BlackBerry smartphone you may see a message like this one.

Select “Don’t ask this again” so that a tick appears in the box, and then choose “YES”.



## Android™

On some Android devices a message about the phonebook transfer appears at the top of the screen.


You must swipe your finger over this message and accept the phonebook transfer request.

## Automatic Transfer Not Supported

Some phones do not support automatic phonebook transfers. If this is the case for your phone the SENSE will announce that it cannot transfer the contacts automatically.


See [“Manually Transferring your Phonebook Contacts” on page 14](#) for help.

**Note:** some phones do not support phonebook transfers at all. If this is the case, the SENSE will read out the caller’s number instead.



## 4: Install the SENSE in your Car

- 1 Slide the clip onto the back of the SENSE until it clicks into place.



- 2 Slide the SENSE onto your car sun visor.




**Don't forget: Drive safely and within the law.**

Please refer to the relevant national or local legislation regarding the usage of mobile devices while driving. Remember that **driving is your first priority**: please read the enclosed safety information booklet for tips on the safe use of your BlueAnt device.

## Answering Calls

When the phone rings, the SENSE will announce the caller's name or number and ask you if you want to take the call. **Wait for the prompt to finish**, and then say **Answer** or **Ignore**:



Or: tap the  symbol at any time to answer the call. Double tap to ignore.

**Tip:** Tap the  symbol to hang up and end the call.

## Making Calls

If your phone supports voice dialing over Bluetooth you can make calls using your voice:

1. Tap the  symbol.
2. The SENSE activates your phone's voice dialing functionality. Please refer to your phone's manual for details on the commands you can use to control your phone.


**Tip:** Tap the  symbol to hang up and end the call.

**Note:** Your phone **must** support voice dialing over Bluetooth:

- > The Apple iPhone 3GS (running firmware 3.1 or higher) and iPhone 4 support this feature, but older iPhone models do not.
- > Most Android phones running Android version 2.2 or above support this feature.
- > Most BlackBerry smartphones support this feature.

## Adjusting the Volume

Swipe your finger across the top of the SENSE to adjust the volume:



Adjusting the volume when you are not on a call sets the volume of the voice prompts.

Adjusting the volume during a call will change the loudness of the caller's voice.

## Redial and Call Back

- > Hold down the + symbol for about 3 seconds to redial the last outgoing call.
- > Hold down the - symbol for about 3 seconds to call back the last incoming call.

## Switching Between Multiple Calls (Call Waiting)\*

- > Tap the - symbol to end your call and answer an incoming call.
- > Tap the + symbol to put your call on hold and answer an incoming call.
- > Tap the + symbol to switch between an active and a held call.

\* To use this feature, your phone and network must support call waiting.

## Pairing Another Phone / Multipoint

To pair another phone, put your SENSE back into pairing mode by holding down the  symbol for about 6 seconds.

- > Your SENSE can store pairing information for up to 2 phones.
- > Your SENSE can connect to up to 2 phones at the same time (multipoint).

When 2 phones are connected at the same time:

- > You can answer calls on either phone through the SENSE.
- > Each time your phones reconnect to the SENSE the one that connects first becomes the "primary phone". If you use the SENSE buttons to activate a feature on your phone (such as redial, call back or phone voice dialing) then this action takes place on the primary phone.

## Transferring your Phonebook Contacts

Your SENSE uses Text To Speech technology (TTS) to read out the name of the person who is calling you. To do this, the SENSE needs to store a copy of your phonebook contacts.

### Automatically Transferring your Phonebook Contacts

When you pair your phone with the SENSE it will attempt to transfer the phonebook contacts automatically. The SENSE stores up to 2,000 contacts per phone.

**Tip:** Tap the ↩ symbol to cancel the phonebook transfer.

### Manually Transferring your Phonebook Contacts

Some phones do not support automatic phonebook transfers: if this is the case on your phone then the SENSE will instruct you to start sending contacts to the SENSE manually. To do this:

1. Wait to be prompted to start sending contacts to the SENSE.
2. Go to your phonebook and select the contacts you want to send to the SENSE. Choose the option to “Mark All” or “Select All” if this is available on your phone (if this is not available, you will need to transfer each contact individually).
3. Select the option on your phone to “send” or “beam” contacts, business cards, or v-cards via Bluetooth, and select the “BlueAnt S3” from the list of Bluetooth devices. See your phone’s manual for help with this step.

**Note:** some phones do not support phonebook transfers at all. If this is the case, the SENSE will read out the caller’s number instead.

## Updating your Phonebook Contacts on the SENSE

If you add or change entries in your phonebook then you need to update the contacts on your SENSE by pressing and holding the + and - symbols together for about 3 seconds.

If you have two phones connected, this updates the phonebook for the primary phone only.

## Reconnecting to the SENSE

Your SENSE includes a sensor that detects the vibration of your car door. This means that the SENSE will automatically reconnect to your phone when you get back in the car.

If the SENSE does not connect to your phone for any reason, tap the  symbol to force the SENSE to reconnect to your paired phone.

**Tip:** On some devices (including BlackBerry, LG, Nokia and Samsung devices), you must make sure you configure your phone to treat the “BlueAnt S3” as an “authorized” or “trusted” connection in the phone’s Bluetooth options.

## Listening to Audio

The SENSE supports A2DP audio streaming. If your phone supports the A2DP profile then simply start playing music or any other audio (including turn-by-turn directions from a GPS application on your phone) and it will automatically transfer to the SENSE.

The streaming audio mutes automatically if the phone rings.

**Note:** When there are two phones connected, only the primary phone can play music through the SENSE via A2DP.

## Reset the SENSE

If you are having problems with your SENSE, you can reset and start again:

1. Delete any pairing information from your phone's Bluetooth pair list. (Remember that the SENSE will be listed on your phone as the "BlueAnt S3").
2. Turn your phone off.
3. Hold down the + and - symbols for about 6 seconds to reset the SENSE.
4. Your SENSE will reset and return to the language selection. Turn your phone back on and follow the prompts on the SENSE to select your language and pair your phone.

## Specifications

- > Bluetooth version 2.1 + EDR
- > Operating Range: Up to 10 meters
- > Talk Time: Up to 20 hours
- > Charging Time: 2.5 hours
- > Supported Profiles: HFP 1.5, A2DP 1.2
- > Frequency: 2.4 GHz
- > Standby Time: Up to 600 hours
- > Battery Type: Rechargeable Lithium Ion

## Help and Support

If you are having trouble getting the SENSE to work, please visit [www.blueantwireless.com](http://www.blueantwireless.com) for online help, support, and troubleshooting tips.

Please contact us before returning the SENSE to a store and we will help you through any difficulty you may have.

## Terms and Conditions

By using this product, you are agreeing to BlueAnt's terms and conditions, available at [www.blueantwireless.com](http://www.blueantwireless.com) and on the supplied warranty information card.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by BlueAnt Wireless is under license.

Android is a trademark of Google Inc., Apple and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. The Trademark BlackBerry® is owned by Research In Motion Limited and is registered in the United States and may be pending or registered in other countries. BlueAnt Wireless is not endorsed, sponsored, affiliated with or otherwise authorized by Research In Motion Limited.

BlueAnt and other trademarks are trademarks of BlueAnt and other organizations and may not be used without permission. The BlueAnt logo is registered in the U.S. Patent and Trademark Office and globally with the World Intellectual Property Organization under the Madrid protocol.

## HELP AND SUPPORT



Visit [register.blueantwireless.com](http://register.blueantwireless.com) to register your BlueAnt device.



Visit [blueantwireless.com/geekspeak](http://blueantwireless.com/geekspeak) to watch and learn with our how-to videos for your BlueAnt device.



Visit [blueantwireless.com/support](http://blueantwireless.com/support) for online help and support or to contact the BlueAnt Technical Support team.



Visit [blueantwireless.com/buy](http://blueantwireless.com/buy) to buy BlueAnt products, accessories and spare parts.



North America	Australia	New Zealand	UK
1 855 9 BLUEANT 1 855 9 258 3268	1300 669 049	0800 443 122	0800 285 1272